

What's included:

- (2) Two front DuroBumps Premium bump stops
- (2) Two JIS 10.9 M8 1.25 mm x 35 mm flange bolts
- (2) Two M8 Flange Nuts
- (1) One FREE sticker

Tools Required:

- Jack and jack stands
- Lug wrench
- Groove-lock pliers, pipe wrench, or similar
- Scraper or wire brush to clean debris
- 12 mm deep socket
- 13 mm open end wrench
- Torque wrench (To Torque wheel nuts)

Instructions:

Pre-soak OEM bump stop with penetrating oil to make removal easier. Pay careful attention to the threaded stud that mounts the bump stop to the hub and the threads of the stud that are exposed beyond the nut.

Step 1: Following vehicle manufacturer recommendations, use a properly rated jack. Raise the front of the vehicle, and support the frame rails with jack stands. Remove the front wheels from the truck. **Be sure to use jack stands!**

Step 2: Both passenger and driver side of the vehicle have (1) OEM bump stops per side located on the Hub assembly. Remove the OEM bump stops.

Step 3: Use a scraper or wire brush and clean any mud/ debris from the frame.

Step 4: Insert provided flange bolt into the new front DuroBumps.

Step 5: Fasten M8 Flange bolt to hub with supplied M8 Flange nut. Tighten nut until snug.

Step 6: Reinstall wheels and lower vehicle back to the ground. Be sure to tighten lug nuts to vehicle manufacturer's recommendations.

Now go hit some trails or cruise the mall ... whatever you're into!



MADE IN THE U.S.A.
www.DuroBumps.com