

What's included:

- (2) Two Bump Stops
- (1) One FREE sticker

Instructions:


Step 1: Remove the Old Strike Pad:

- Unscrew the mounting bolt retaining the plastic strike pad on your hydraulic bump stop.
- Remove the plastic strike pad.

Step 2: Install DuroBumps No-Thuds:

- Insert DuroBumps No-Thuds, aligning the holes with the metal receiving cup.
- Use the original mounting hardware to fasten the No-Thuds to the hydraulic bump stop.

Now go hit some trails or cruise the mall ... whatever you're into!



MADE IN THE U.S.A.
www.DuroBumps.com