

**What's included:**

- (2) Rear DuroBumps
- (2) Standard mounting plates
- (4) Flat head screws
- (6) M8 x 1.25 – 30mm bolts
- (1) Hex Allen wrench
- (1) Free sticker

**Tools Required:**

- Jack and jack stands
- Wheel lug wrench
- 12mm deep socket wrench
- Torque wrench

**Instructions:**

**Step 1:** Following the vehicle manufacturer's recommendations, use a properly rated jack and jack stands. Lift the rear of the truck with the floor jack and support the vehicle using jack stands. Remove the rear wheels.

**Step 2:** Remove the OEM bump stop located on the frame rail above the rear axle tube using a 12mm deep socket. There are three bolts securing each bump stop.

**Step 3:** Use a scraper or wire brush to clean any mud or debris from the frame.

**Step 4:** Assemble the rubber bump stop to the metal bracket using the provided flat head screws. Fasten the screws with the supplied Allen wrench until snug. Do not overtighten.

**Step 5:** Mount the DuroBumps bump stop in the OEM location on the frame rail. Insert the bolts into the factory holes and tighten them using a 12mm socket wrench until snug. Do not overtighten.

**Step 6:** Repeat steps 2–5 on the other side of the vehicle.

**Step 7:** Reinstall the wheels and lower the vehicle back to the ground. Torque the lug nuts to factory specifications.

**Now go hit some trails or cruise the mall ... whatever you're into!**



**MADE IN THE U.S.A.**  
*www.DuroBumps.com*